




Deutsch Connectors Used in the JWR Bugeye




JWR Bugeye Dash Wiring to Connector “A”




JWR Bugeye Dash Wiring to Connector “B”



JWR Bugeye Dash Wiring to Connector “C”




JWR Bugeye
Dash Wiring to Connector “D” Front
Loom




JWR Bugeye Hazard Switch Connector “E”

Hazard
Switch



JWR Bugeye Dash Wiring to Connectors "G" & "H" With Fuses 1-9



JWR Bugeye Dash Wiring to Connector “J”

